RIM Shaker
SKR

RIM SHAKER

Der Rim (engl. Rand/Kante) Shaker kombiniert einen flexiblen Träger und ein quadratisches Shaker-Rohr aus Kunststoff, das in dem Träger befestigt ist.
Mittels Klett an der Seite eines Cajons (oder praktisch jeder Trommel, deren Schlagfläche im 90° Winkel zum Resonanzkörper steht) angebracht, steht der Shaker parallel zur Schlagfläche.
Dadurch hat man einen Shaker für das freie Handspiel, ohne ihn greifen zu müssen.

Der Sound lässt sich in jedes Rhythmus-Pattern im natürlichen Bewegungsablauf einfach einweben.
Unterbrechungen im Spielfluss durch Wechsel des Instruments im Setup ist nicht nötig.
Das Ende des Shakerrohrs ist mit einem kleinen Vliesband umwickelt, so kann die Spielfläche über das Röhrchen angeschlagen werden.

Es erzeugt einen Klang ähnlich des Anspiels der Schlagfläche mit der Fingerspitze, was die Klangmöglichkeiten mit dem Rim Shaker noch erweitert.
Mit einem auf dem Shakerrohr beweglichen Gummiring lässt sichder Attack des Anschlages auch einstellen.
Der Rim Shaker ist eine fantastische, flexible Sound-Ergänzung zu jedem bestehenden Setup, auch für abenteuerlustige Gitarristen geeignet.

Details

- Quadratisches Shakerröhrchen
- Flexible 90° Eckverbindung
- Verwendbar bei allen Instrumenten mit einer 90° Ecke
- Klettverbindung
- Intuitiv spielbar durch Antippen oder Schlagen
- Maße: ca. 125 x 115 x 55 mm
- Gewicht: ca. 70g

Der RIM Shaker präsentiert sich auf einem naturbraunen Displaykarton zur Aufhängung an einem

Schlagwerk GmbH
Brueckenstrasse 10
73333 Gingen
Germany

Telefon: +49 (0)7162 / 948 964 0

Email: info@schlagwerk.com
Web: www.schlagwerk.com

RIM Shaker
SKR

RIM SHAKER

The Rim Shaker combines a flexible carrier and a square shaker tube attached to the carrier. Attached by velcro to the side of a cajon (or virtually any drum whose playing surface is at a 90° angle to the shell), the shaker aligns parallel to the playing surface.
This puts a shaker at your fingertips without having to grab it, playable by simply hitting it.

The sound can be easily woven into any rhythm pattern in the natural flow of movement.
No more interruptions in the flow of playing for changing the instrument in the setup.
The RIM Shaker is presented on a natural brown display box for hanging on a standard product carrier (with Euro perforation). No plastic is used in the packaging.

The end of the shaker tube is wrapped with a small fleece band, so the playing surface can be struck via the tube. It produces a sound similar to a fingertip, which further expands the sound possibilities with the Rim Shaker.

With a rubber ring that moves on the shaker tube, you can also adjust the attack of the stroke. The Rim Shaker is a fantastic, flexible sound addition to any existing setup, also suitable for adventurous guitarplayers.

Details

- Square Shaker tube
- Flexible 90° corner assembly
- Can be applied to any instruments providing a 90° edge
- Velcro attachment
- Naturally playable by tapping or hitting
- Dimensions: approx. 125 x 115 x 55 mm
- Weight: approx. 70g

Schlagwerk GmbH
Brueckenstrasse 10
73333 Gingen
Germany

Phone: +49 (0)7162 / 948 964 0

Email: info@schlagwerk.com
Web: www.schlagwerk.com